# EnzyChrom<sup>™</sup> Glycerol Assay Kit (Cat# EGLY-200)

Quantitative Colorimetric/Fluorimetric Glycerol Determination

### DESCRIPTION

GLYCEROL [GLYCERIN or GLYCERINE, C<sub>3</sub>H<sub>5</sub>(OH)<sub>3</sub>] is widely used in foods, beverages and pharmaceutical formulations. It is also a main byproduct of biodiesel production. Simple, direct and automation-ready procedures for measuring glycerol concentrations find wide applications. BioAssay Systems' glycerol assay uses a single Working Reagent that combines glycerol kinase, glycerol phosphate oxidase and color reactions in one step. The color intensity of the reaction product at 570nm or fluorescence intensity at λem/ex = 585/530nm is directly proportional to glycerol concentration in the sample.

# **KEY FEATURES**

Sensitive and accurate. Use as little as 10 µL samples. Linear detection range in 96-well plate: 10 to 1000 µM (92 µg/dL to 9.2 mg/dL) glycerol for colorimetric assays and 2 to 50 µM for fluorimetric assays.

Simple and convenient. The procedure involves addition of a single working reagent and incubation for 20 min at room temperature, compatible for HTS assays.

Improved reagent stability. The optimized formulation has greatly enhanced the reagent and signal stability.

#### **APPLICATIONS:**

Direct Assays: glycerol in biological samples (e.g. serum and plasma). Drug Discovery/Pharmacology: effects of drugs on glycerol metabolism. Food and Beverages: glycerol in food, beverages, pharmaceutical formulations etc.

### **KIT CONTENTS**

Assay Buffer: 24 mL Enzyme Mix: 500 µL **ATP**: 250 μL Dye Reagent: 220 µL Standard: 100 µL 100 mM Glycerol

Storage conditions. The kit is shipped on ice. Store all components at -20°C. Shelf life of 12 months after receipt.

Precautions: reagents are for research use only. Normal precautions for laboratory reagents should be exercised while using the reagents. Please refer to Material Safety Data Sheet for detailed information.

## **COLORIEMTRIC 96-WELL PROCEDURE**

Note: SH-group containing reagents (e.g. mercaptoethanol, DTT) may interfere with this assay and should be avoided in sample preparation.

1. Equilibrate all components to room temperature. Keep thawed Enzyme Mix in a refrigerator or on ice. Dilute standard in distilled water as follows (diluted standards can be used for future assays when stored refrigerated).

No	STD + H <sub>2</sub> O	Vol (μL)	Glycerol (mM)
1	10 μL + 990 μL	1000	1.0
2	6 μL + 994 μL	1000	0.6
3	3 μL + 997 μL	1000	0.3
4	0 սL + 1000 սL	1000	0

Transfer 10 µL standards and 10 µL samples into separate wells of a clear 96-well plate.

- 2. For each reaction well, mix 100 µL Assay Buffer, 2 µL Enzyme Mix, 1  $\mu$ L ATP and 1  $\mu$ L Dye Reagent in a clean tube. This Working Reagent should be used on the same day of preparation. Transfer 100  $\mu$ L Working Reagent into each reaction well. Tap plate to mix.
- 3. Incubate 20 min at room temperature. Read optical density at 570nm (550-585nm).

Note: if the Sample OD is higher than the Standard OD at 1.0 mM, dilute sample in water and repeat the assay. Multiply result by the dilution factor.

## CALCULATION

Subtract blank OD (water, #4) from the standard OD values and plot the OD against standard concentrations. Determine the slope using linear regression fitting. The glycerol concentration of Sample is calculated as

$$[Glycerol] = \frac{OD_{SAMPLE} - OD_{H2O}}{Slope} \quad (mM)$$

OD<sub>SAMPLE</sub> and OD<sub>H20</sub> are optical density values of the sample and water. Conversions: 1mM glycerol equals 9.2 mg/dL, 92 ppm.

#### FLUORIMETRIC 96-WELL PROCEDURE

For fluorimetric assays, the linear detection range is 2 to 50 µM glycerol. Mix 10 µL 100 mM Standard with 990 µL H<sub>2</sub>O (final 1 mM).

No	1 mM STD + H <sub>2</sub> O	Vol (μL)	Glycerol (mM)
1	50 μL +  950 μL	1000	0.050
2	30 μL +  970 μL	1000	0.030
3	15 μL +  985 μL	1000	0.015
4	0 μL +1000 μL	1000	0

Dilute standards as above. Transfer 10  $\mu$ L standards and 10  $\mu$ L samples into separate wells of a black 96-well plate.

Add 100 µL Working Reagent (see Colorimetric Procedure). Tap plate to mix.

Incubate 20 min at room temperature and read fluorescence at  $\lambda_{ex}$  = 530nm and  $\lambda_{em}$  = 585nm.

The glycerol concentration of Sample is calculated as

$$[Glycerol] = \frac{F_{SAMPLE} - F_{H2O}}{Slope} \quad (mM)$$

## MATERIALS REQUIRED, BUT NOT PROVIDED

Pipeting devices, centrifuge tubes, Clear flat-bottom 96-well plates, black 96-well plates (e.g. Corning Costar) and plate reader.



## PUBLICATIONS

1. Bahar, B et al. A potential role of IL-6 in the chitooligosaccharide-mediated inhibition of adipogenesis (2011). Br J Nutr. 106(8):1142-1153.

2. Drew, BG et al (2011). Reconstituted high-density lipoprotein infusion modulates fatty acid metabolism in patients with type 2 diabetes mellitus. J Lipid Res 52(3):572-581.

3. Wachtler, B et al (2011). From attachment to damage: defined genes of Candida albicans mediate adhesion, invasion and damage during interaction with oral epithelial cells. PLoS One 6(2):e17046.

HANDHELD READER PROCEDURE: please visit our website www.bioassaysys.com (Section "Handheld Readers").